

Model	Year(s)	Type	Plays	Observed		Probable		Box indicates known Qty.	
				Low	High	Low	High	Quantity	Notes
Debutante	1933	Jukebox	10	249,666	249,666				
P-10	1934-35	Jukebox	10	0226	4,177	0101	4,593	4,493	
P-20	1934-35	Jukebox	10	3,096	3,106			4,780	
P-12	1935	Princess Jukebox	12	5,066	17,583	5,001	18,000	13,000	
P-30	1935	Modern Jukebox	12	30,246	30,995	30,001	30,996	996	
35	1935	Jukebox	12	35,050	35,052	35,001	35,100	100	
P-400	1935	Deluxe Jukebox	12	40,009	40,948	40,001	41,000	1,000	
312	1936	Modern Jukebox	12	42,930	49,416	42,001	50,002	8,002	
412	1936-37	Standard Jukebox	12	63,504	97,085	60,001	98,000	38,000	
400	1936	Deluxe Jukebox	12	110,001	111,365	110,001	111,400	1,400	
316	1937	Modern Jukebox	16					1,000	
716	1937	Jukebox	16	A01140A	A03611A	1,001	3,700	2,700	
616	1937	Jukebox	16	A20189A	A43162A	20,001	43,706	23,706	616 / 616A area is a mess. Doubt that 51,706 were made
616A	1937	Jukebox (A = magnetic coin)	16	A24265A	A41115A				
616A	1937	Jukebox (A = magnetic coin)	16	58,099	58,099				
616A	1937	Jukebox (A = magnetic coin)	16	200,860	214,631	200,001			
616	1937	Jukebox	16	213,565	227,719		228,000	28,000	
416	1937	Standard Jukebox	16	A60123A	A60907A	60,001	61,003	1,003	
410	1940-41	Countertop Base		115,092	115,430	115,001	115,500	500	
430	1942-43	Organ Pipe Selective Speaker w 125	24	120,224	121,787	120,001	121,900	1,900	
710	1940-41	Countertop Base		130,016	131,707	130,001	132,000	2,000	
301B	1942	Wall Box Adapter (uses some wood)	24	140,535	140,920	140,001	141,000	1,000	
100	1941-42	Multi-Wire Wall Box	24	141,021	169,256	141,001	170,000	29,000	
111	1941-42	Dual-Wire Bar Box	24	170,579	171,503	170,001	171,700	1,700	
115	1941-42	Wireless Wall Box	24	180,131	181,221	180,001	181,250	1,250	
120	1941-42	Dual-Wire Wall Box	24	190,038	206,211	190,001	206,500	16,500	
42	1942-45	Model 42 (wood and glass)		206,596	242,402	206,501	243,000	36,500	
24 / 24A	1938	Jukebox (A = magnetic coin)	24	240,189	256,628	240,001	257,000	17,000	
340	1940-42	Music Receiver only for 340, 350, 140		280,070	280,283	280,001	280,300	300	
580	1942	Tulip Selective Speaker	24	285,129	285,846	285,001	285,900	900	
300	1940	Wall Box Adapter	24	304,507	304,507	300,001	305,000	5,000	
301A	1941	Wall Box Adapter	24						
310	1940	Multi-Wire Wall Box	24	310,016	315,854	310,001	316,000	6,000	
330	1940	Dual Wire Bar Box w Two Selectors	24			320,001	320,300	300	
331	1940	Dual Wire Bar Box w One Selector	24	331,032	331,996	330,001	332,000	2,000	
332	1940	Dual Wire Bar Box w Large Program	24	340,213	341,456	340,001	341,500	1,500	
320	1940	Sweet Music Wall Box	24	351,883	359,995	350,001	360,000	10,000	See 502,001

Model	Year(s)	Type	Plays	Observed		Probable		Box indicates known Qty.	
				Low	High	Low	High	Quantity	Notes
304	1940	Impulse Stepper	24	360,769	367,680	360,001	368,000	8,000	
305	1940	Impulse Receiver	24	370,417	371,356	370,001	371,500	1,500	
360	1940-41	Impulse Transmitter for 300 series	24	375,998	379,042	375,001	380,000	5,000	
361	1941-42	Impulse Transmitter for 100 series	24						
340	1940	Stroller with 320 Wall Box	24	385,033	385,240	385,001	385,300	300	
350	1940	Burl Wireless Speaker "Music By Wurlitzer"		390,081	390,215	390,001	390,250	250	
306	1940-42	Music Transmitter		395,190	395,448	395,001	395,500	500	
41	1940-41	Countertop Jukebox	12	400,017	401,961	400,001	402,010	2,010	
421	1942-43	Organ Pipe Wireless Speaker		405,083	405,095	405,001	405,150	150	
71	1940	Countertop Jukebox	12	420,372	424,357	420,001	424,506	4,506	
700	1940	Standard Jukebox	24	440,117	449,145	440,001	449,498	9,498	
130	1941-42	Wall Box Adapter	24	452,663	452,663	450,001	453,000	3,000	
800	1940	Deluxe Jukebox	24	461,899	471,208	460,001	471,501	11,501	
50	1937-38	Console Jukebox	12	500,014	500,817	500,001	501,180	1,180	
320	1940	Sweet Music Wall Box	24	502,178	512,078	502,001	512,500	10,500	Total 20,500
130A	1941-42	Wall Box Adapter	24	516,452	518,945	515,001	519,000	4,000	
135	1941-42	Step Receiver	24	530,135	530,963	530,001	531,000	1,000	
140	1941	Wireless Stroller with 115 Wall Box	24						
140A	1941	Wireless Stroller	24	535,067	535,166	535,001	535,200	200	
140B	1941-42	Wireless Stroller with 115 Wall Box	24						
140C	1942	Wireless Stroller with 123 Wall Box	24						
145	1941-42	Impulse Stepper	24	539,752	547,582	538,001	548,000	10,000	
51	1937-38	Countertop Jukebox	12	550,065	551,214	550,001	551,250	1,250	
61	1939-40	Countertop Jukebox	12	570,011	583,401	570,001	584,000	14,000	
600/600A	1939	Rotary Jukebox (A = magnetic coin)	24	600,090	612,627	600,001	613,000	13,000	
P-500/500A	1939	Deluxe Jukebox (A = magnetic coin)	24	650,281	675,375	650,001	676,000	26,000	
810	1941-42	Countertop Base		675,180	676,288	675,001	676,300	1,300	
K600/K600A	1938-39	Keyboard Jukebox (A = magnetic coin)	24	700,151	712,240	700,001	713,000	13,000	
81	1941-42	Countertop Jukebox	12	720,001	720,990	720,001	721,100	1,100	
750	1941	Standard Jukebox	24	740,029	746,001	740,001	746,411	6,411	
750E	1941-42	Standard Jukebox	24	752,772	759,995	750,001	760,000	10,000	See 765,001
780	1941	Colonial Jukebox	24	760,002	762,897	760,001	763,000	3,000	
750E	1941-42	Standard Jukebox	24	765,480	769,416	765,001	770,000	5,000	See 778,501
780E	1941-42	Colonial Jukebox	24	772,510	778,153	770,001	778,500	8,500	
750E	1942	Standard Jukebox	24	778,563	778,997	778,501	779,000	500	Total 15,500
850	1941	Peacock Jukebox	24	780,004	789,976	780,001	790,002	10,002	
850A	1942	Tulip Jukebox	24	790,047	790,448	790,003	790,458	456	

Model	Year(s)	Type	Plays	Observed		Probable		Box indicates known Qty.	
				Low	High	Low	High	Quantity	Notes
220	1940-41	Portable Walnut Speaker		800,085	800,235	800,001			See 220A below
250	1940-41	Burl Speaker "Music By Wurlitzer"		800,279	800,279				See 250A below
39A	1939-42	Round Speaker "Strike Up The Band"		800,997	801,891				
160	1938-42	Maple Speaker		801,779	805,541				
170	1938-41	Plastic Clamshell Speaker							
220A	1940	Portable Walnut Speaker		802,406	802,476				See 220 above
250A	1940-41	Burl Speaker "Music By Wurlitzer"		803,319	803,876				See 250 above
38	1939	Auxiliary Speaker							
39	1939-41	Round Speaker "Strike Up The Band"		804,599	805,604				
36	1940-42	Gray Unlit Speaker							
210	1940-42	Auxiliary Speaker							
240	1941-42	Outdoor Speaker							
420	1942-43	Organ Pipe Speaker		805,045	805,460			500	See 421 above
425	1942-43	Organ Pipe Corner Speaker		806,247	806,366			100	
107	1941-42	Wireless Bar Box	24						
108	1942	Sloped Wireless Bar Box	24						
112	1942	Sloped Dual-Wire Bar Box	24						
123	1941-42	Wireless Wall Box	24	850,149	850,449	850,001	850,500	500	
125	1941-42	Dual-Wire Wall Box	24	860,048	877,117	860,001	877,200	17,200	
950	1942	Gazelle Jukebox	24	900,001	903,467	900,001	903,497	3,497	
1015	1946	Bubbler Jukebox	24	1,000,009	1,041,889	1,000,001	1,042,000	42,000	See 2,050,000
3031	1946-50	Multi-Wire Wall Box	24	1,050,146	1,085,533	1,050,001	1,086,000	36,000	
3020	1946-50	Universal Wall Box	24	1,100,389	1,153,174	1,100,001	1,154,000	54,000	
4000	1946-50	Silver Star Speaker		1,361,158	1,365,490	1,360,001	1,365,500	5,500	
4002	1946-49	Colored Plastic Star Speaker		1,391,014	1,394,869	1,390,001	1,395,500	5,500	
215	1948-50	Impulse Transmitter		1,421,017	1,440,513	1,420,001	1,441,000	21,000	
216	1946-47	Red Impulse Receiver		1,481,192	1,490,896	1,480,001	1,491,000	11,000	
216	1948-50	Silver Impulse Receiver							
4003	1946-49	Scroll Speaker		1,566,263	1,568,283	1,565,001	1,568,500	3,500	
4004	1946-49	Johnny One Note Speaker		1,587,131	1,587,311	1,585,001	1,588,000	3,000	
4004-A	1948-49	Johnny One Note Speaker w Trans.		1,588,199	1,588,679	1,588,001	1,589,000	1,000	
3025	1946-47	Painted 3-Wire Wall Box	24	1,600,001	1,601,869	1,600,001	1,602,000	2,000	
3025	1947-50	Nickeled 3-Wire Wall Box	24	1,602,483	1,607,198	1,602,001	1,608,000	6,000	8,000
3045	1946-47	Painted Wireless Wall Box	24	1,650,290	1,656,957	1,650,001	1,657,000	7,000	
3025		Nickeled 3-Wire Wall Box (was 3045)	24	1,654,123	1,657,049				Were 3045's
3045	1948-50	Nickeled Wireless Wall Box	24	1,656,727	1,656,727				

Model	Year(s)	Type	Plays	Observed		Probable		Box indicates known Qty.	
				Low	High	Low	High	Quantity	Notes
219	1945	Red Impulse Stepper (RS serial)	24	1,868,617	1,869,043	1,868,001	1,870,000	2,000	
219	1946-47	Red Impulse Stepper	24	1,870,074	1,874,754	1,870,001	1,875,000	5,000	Red 12,000
219	1947	Red Impulse Stepper with 3 fuses	24	1,875,876	1,878,566	1,875,001	1,880,000	5,000	
219	1948	Silver Stepper with Silver Transformer	24	1,880,384	1,881,891	1,880,001	1,882,000	2,000	Silver
219	1948-49	Silver Stepper with Black Transformer	24	1,882,329	1,886,822	1,882,001	1,887,000	5,000	7,000
1017	1946-47	Hideaway Jukebox	24	1,918,134	1,919,802	1,917,001	1,920,312	3,312	
1080	1945-47	Colonial Jukebox	24	1,945,008	1,950,696	1,945,001	1,952,604	7,604	
4005 / A	1947-50	Round Walnut Speaker		2,000,170	2,003,788	2,000,001	2,004,000	4,000	
4006 / A	1947-50	Round Mirror Speaker		2,010,005	2,011,953	2,010,001	2,012,000	2,000	
4007	1947-50	Oval Deluxe Speaker		2,020,084	2,020,999	2,020,001	2,021,000	1,000	
4008	1947-50	Super Deluxe Speaker		2,030,006	2,030,930	2,030,001	2,031,000	1,000	
4009	1947-51	Recessed Speaker							
241	1947-50	Outdoor Speaker		347	347			500	
1015	1947	Bubbler Jukebox	24	2,050,348	2,069,499	2,050,001	2,070,000	20,000	See 1,000,001
1100	1948-49	Jukebox	24	2,100,002	2,135,942	2,100,001	2,136,000	36,000	
1080A / C	1948-49	Colonial Jukebox	24	2,150,022	2,151,105	2,150,001	2,151,200	1,200	
1017A	1948-49	Hideaway Jukebox	24	2,170,187	2,171,106	2,170,001	2,171,500	1,500	
227	1948-49	Auxiliary Amplifier		2,182,203	2,183,147	2,180,001	2,184,000	4,000	
2140	1948-50	Frog Barbox	24	2,200,281	2,209,850	2,200,001	2,210,000	10,000	Four per 212
212	1948-50	Frog Master Unit - Wireless	24	2,300,874	2,302,427	2,300,001	2,302,500	2,500	

Oddballs

700C	1940	RCA Canada Std Jukebox	24	0207					
750C	1941	RCA Canada Std Jukebox	24	518					
1015	1947	Bubbler Jukebox	24	2,122,749					Two-thirds thru 1100 serial range.

Amplifiers provide production clues

771	1937	Jukebox Amplifier		A20467A	A20467A				
851	1938-39	Jukebox Amplifier 24 600		242,590	247,078				
700	1940	Jukebox Amplifier		444,920	444,920	440,001			
841	1938-39	Countertop Jukebox Amplifier		575,276	581,740	570,001		10,000	
854	1938-39	Jukebox Amplifier 500		663,096	665,089				
501	1941	Jukebox Amplifier 750 850 etc.		749,829	769,599	740,001		48,366	
503	1946	Jukebox Amplifier		1,017,468	1,033,552	1,000,001		49,604	
503	1947	Jukebox Amplifier		2,054,412	2,054,568	2,050,001		20,000	
506	1946	Jukebox Amplifier		2,109,117	2,109,117	2,100,001		37,200	